

# Mat Cleaning

Easy Maintenance for Industrial Environments



The power of control. Automated.

**Use the following procedures to clean any Larco mat, including the Larco SureStep non-skid mat.**

## Recommended Cleaners:

- Most good quality industrial cleaners/degreasers are acceptable. NOTE: cleaning solutions that contain phosphates, chlorine, organic solvents or mineral spirits should NOT be used.
- Be sure to read and follow all manufacturers' directions, recommendations, warnings and proper disposal procedures for all cleaning solutions.
- Wear all recommended safety equipment.



## Pressure Washing and Steam Cleaning:

This method is not recommended for Comfort Step anti-fatigue mats.

- Remove any loose debris from the mat surface before beginning the cleaning process.
- Use a flat fan spray nozzle with a pattern angle of 15 degrees or more.
- Keep spray distance 12 inches (305 mm) or more away from the mat surface.
- Spray pressure should not exceed 1,500 psi (103.4 Bar)
- Water temperature should not exceed 190° F (88° C)
- Keep the spray pattern moving; do not concentrate it in one location for an extended period of time.
- Heavily soiled mats should be pre-soaked for 10 minutes with the mixed cleaning solution. Areas can be brushed with a hand utility brush.
- When cleaning is completed, rinse with clean water.

## Brush Cleaning

- Remove any loose debris from the mat surface before beginning the cleaning process.
- Heavily soiled mats may require pre-soaking for 10 minutes with a liberal application of pre-mixed cleaner.
- Clean the mat with a good utility brush made of Nylon, Palmyra, Natural Bassine Tampico or similar material.
- When cleaning is completed, rinse with clean water.

## Good Cleaning Practices Should be Utilized During Cleaning Operations

- Wear safety glasses and all recommended safety gear.
- Install safety signs indicating wet floors.
- Install safety barriers where required.
- Turn off required electrical connections.
- Cover all equipment that can be damaged by cleaning.
- Be sure the area is completely dry before removing safety barriers and signs and restoring electrical connections.



223-0119-000 Rev. C 5/19  WARNING: Cancer and Reproductive Harm - [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

ATEK Access Technologies  
10025 Valley View Road, Ste. 190  
Eden Prairie, MN 55344 U.S.A.

PH: 1.800.523.6996  
FAX: 1.800.589.3705  
+1.218.829.9797

[www.atekaccess.com](http://www.atekaccess.com)



Access the power of technology.